


## Safety Warning

- Only professional technicians are allowed for installation and maintenance.
- Installation in any damp, condensed-phase environment with inflammable and explosive gas is forbidden.
- You are prohibited from touching the conductive part when the product is operating.
- Do not install the product at places where gas medium can cause metal corrosion and insulation damage.
- After installing the product, finishing the inspection of load side line and splitting the fire-resistance circuit, the controller must be set to "Manual" position and the product must be set to split position. Switch the controller to "Auto" position after line fault is eliminated.
- To avoid dangerous accidents, the products should be installed and secured according to the instructions.
- This product is applicable to environment A. The product will generate harmful electromagnetic interference if used in environment B, in which case, user should take proper protective measures.

### 1 Application Information

a) The normal application temperature of the product is  $-5^{\circ}\text{C} \sim +40^{\circ}\text{C}$ .  
 Note: If you need to use the product under  $-25^{\circ}\text{C} \sim +70^{\circ}\text{C}$ , please consult the manufacturer.  
 b) If you need to use the product above 2000m altitude, please consult the manufacturer;  
 c) Pollution class: Class 3;  
 d) Installation category of main circuit: III;  
 e) Enclosure protection class: IP20.

### 2 Inspection and Test



1. Determine product technical parameters.  
 2. Remove the signal sampling line of the control circuit of the controller at the incoming end of the product before conducting insulation test.

OFF lock-up function. The product must be set to manual mode and at disconnected position, the keyhole diameter is  $\Phi 5.5$ .

Fig 1 Inspection and test

01

### 3 Outline and Installation Dimensions





Fig 2 Outline and installation dimensions

02

### 4 Installation and Wiring




Fig 3 Installation and wiring

Tabla 1 Sectional area, width and number of copper wire

| Safe current (A)                              | 20  | 25     | 32 | 40 | 63 |
|---|-----|--------|----|----|----|
| Copper wire sectional area (mm <sup>2</sup> ) | 2.5 | 4      | 6  | 10 | 16 |
| Copper wire width (mm)                        |     | ≤6     |    |    |    |
| Copper wire number                            |     | 1      |    |    |    |
| Insert copper wire length (mm)                |     | 15±1±9 |    |    |    |

03




Fig 4 The type of controller




fig5-1



fig5-2

04




Fig 5 Terminal wiring diagram

### 5 Display and Operation Interface




Fig 6 Display and operation interface

05

### Table 2 Indicator information

| Indicator information                  | ①             | ②             | ③             | ④             |
|--|---------------|---------------|---------------|---------------|
| The normal power supply is normal      | Constantly ON |               |               |               |
| The normal power is closed             |               | Constantly ON |               |               |
| The alternative power supply is normal |               |               | Constantly ON |               |
| The alternative power is closed        |               |               |               | Constantly ON |
| Transfer delay                         |               |               |               | Flashing      |
| Return delay                           |               | Flashing      |               |               |
| Normal circuit breaker trips           | Flashing      | Flashing      |               |               |
| Alternative circuit breaker trips      |               |               | Flashing      |               |
| Product transfer fault                 | Flashing      |               | Flashing      |               |
| Fire protection linkage                |               | Flashing      | Flashing      | Flashing      |

### 6 Product Troubleshooting

Transfer tests on the product are recommended with an interval of three months.

### Table 3 Common faults and eliminations

| Common fault symptoms                               | Fault reason   | Fault elimination method  |
|---|--|---|
| The controller indicator is not lit after power on. | The power sampling lines are in poor contact or have broken off.<br>The 3 Pole product(neutral) is not connected to the terminals.<br>A product fuse has been blown.   | Check the corresponding wires and make correct connections.<br>Replace the fuse.  |
| Four indicators flash at the same time.             | Phase loss or failure.<br>Self-protection of the chips of the controller power supply.   | Check normal voltage of the normal circuit.<br>Power on the device again about 10 minutes after power-off.  |
| Controller failure.                                 | Controller failure.  | Replace the controller.   |
| The controller indicator indicates tripping.        | A fault in the normal circuit causes the circuit breaker to trip.<br>Phase loss of the actuation circuit breaker (Phase A,Phase N).<br>The normal/alternative circuit breaker on the product load side is not wired according to product instructions,especially in Phase A and Phase N. | Examine and eliminate the fault in the normal circuit.<br>Replace the controller or the product.<br>Make wiring according to the User Manual and check if the sampling wire has loosened. |

### 7 Environmental Protection

In order to protect the environment, the product or product parts should be disposed of according to the industrial waste treatment process, or be sent to the recycling station for assortment, dismantling and recycling according to local regulations.

06

## QC PASS

NXZB-63、NXZHB-63  
Automatic Transfer Switch  
IEC/EN 60947-6-1

### PD1 Check 15

Test date: Please see the packing

ZHEJIANG CHINT ELECTRICS CO., LTD.

CHINT  
CHINT ELECTRICS  
NXZB-63、NXZHB-63  
Automatic Transfer Switch  
User Instructions

Zhejiang Chint Electrics Co., Ltd.  
Add: No.1, CHINT Road, CHINT Industrial Zone, North Baixiang,  
Yueqing, Zhejiang 325603, PR.China  
E-mail: global-sales@chint.com  
Website: http://en.chint.com



NXZB-63、NXZHB-63  
Automatic Transfer Switch

## User Instructions

NO:2020.03

Standard: IEC/EN 60947-6-1